



A V 8 6

INSTRUCTIONS

1564 SUNRISE

INTRODUCTION


The 1564 Sunrise Automatic is made for early starts, long days and wherever you end up.

At 9 o'clock, the 24-hour subdial follows the time across a full day. Set against a deep blue backdrop, the illustrated sun emerges through the clouds. More than a way of displaying 24-hour time, its distinctive design ultimately gave the 1564 Sunrise Automatic its name.

From first light to last call, Sunrise is designed for the hours that make up a day and everything that can happen in between.

SPECIFICATIONS

Caliber:	Miyota 9120 Automatic
Power reserve:	40 Hours
Glass:	Double domed sapphire glass
Water Resistance:	5.ATM – Water tested to 50 meters.



HOW TO SET DAY, DATE, TIME AND MONTH

1. **DAY:** Adjust the day by rotating the crown counter-clockwise in "B" position.
2. **DATE:** Adjust the date by rotating the crown clockwise in "B" position.
3. **TIME:** Rotate the crown in "C" position and adjust the standard time.
4. **MONTH:** Push the button "D" and adjust the month.

HOW TO WIND UP THE MAINSPRING

1. Turning the crown in "A" position. Wind 15~20 times clockwise until second hand starts to move naturally.

ACCURACY

1. Static Accuracy : -10~+30 seconds per day



A V 8 6

CELEBRATE YOUR MOMENT

Go to www.AV86.com for warranty information